



Tools and Supplies

Utility knife, spacers, pencil, tape measure, ruler, and safety goggles.

Installation

Start in a corner by placing the first plank with the tongue side facing the wall. Use spacers along each wall to maintain an expansion space of 5/16 in - 3/8 in between the wall and the flooring

To attach the second plank, insert the end tongue into the end groove of the very first plank at an angle of approx. 15-20 degrees. When lowered, the plank will click into place. Line up edges carefully. The planks should be flat to the floor.

Continue connecting the first row until you reach the last full plank. Fit the last plank by rotating the plank 180 degrees with the pattern side upward, place beside row. Measure and mark, then using a ruler and utility knife, score the plank and snap off. Attach as described above.

Begin the next row with the off cut piece from the previous row to stagger the pattern. Pieces should be a minimum of 8 in long and joint offset should be at least 16 in

Note: It is faster to assemble planks into a new row at the ends and then attached the entire row to the previous row on the long sides.

To start your next row, lay your first plank on the subfloor. Take your second plank, insert the end tongue into the end groove of the first plank at an angle of approx. 15-10 degrees. When lowered the plank will click into place with light pressure. The planks should be flat to the floor. Make sure gaps are as small as possible. Continue assembling the planks this way until you have your second row complete.

To attach the second row to the first row, tilt and push the side tongue into the side groove of the first panel at an angle of approx. 15-20 degrees. Lower and click into place lining the edges up carefully. Continue laying remaining planks in this manner.

To fit the last row, lay a plank on top of the previous row. With the tongue to the wall, lay another plank upside down on the one to be measured and use it as a ruler. Don't forget to allow room for spacers. Cut the plank and attach into position.

Door Frames and heating vents also require expansion room. First cut the plank to the correct length. Then place the cut plank next to its actual position and use a ruler to measure the areas to be cut out and mark them. Cut out the marked points allowing the necessary expansion distance on each side.

You can trim door frames by turning a plank upside down and using a handsaw to cut away the necessary height to that planks slide easily under the frames.

Care and Maintenance

Sweep regularly to remove surface grit and dust. Use a damp cloth or mop to clean up any dirt and footprints but avoid using excessive moisture. All spills should be cleaned up immediately. CAUTION: Planks are slippery when wet! Do not use a wet spray micro fiber mop. Never use wax, polish, abrasive cleaners or scouring agents as they may dull or distort the finish. High heels can damage floors. Use protective pads under furniture. Use doormats at entrance ways to protect floor from discolouring. Do not allow pets with unclipped nails to scratch or damage the floor. Avoid exposure to direct sunlight for prolonged periods of time. Use drapes or blinds to minimize direct sunlight during peak sunlight hours. It is a good idea to save a few planks in case of accidental damage. Planks can be replaced or repaired by a flooring professional.